UMK

CSK





## 5-PHASE STEPPING MOTOR AND DRIVER PACKAGE

# **CSK** Series

Features ·····	.∙B-176
Standard Type	.∙B-179
TH Geared Type	∙∙B-185
List of Motor and Driver Combinations	.∙B-190
Wiring Diagrams	.∙B-191
Adjusting the Output Current	.∙B-193

## 5-PHASE STEPPING MOTOR AND DRIVER PACKAGE













# 1. High torque

The PK high torque motor was designed to produce high-torque in a compact frame size.

## Low vibration

Because there is no noticeable resonance, smooth rotation is achieved. These package keep vibration and noise levels low.

# 3. Compact package

Both the motor and driver are designed to be compact, making them perfect for reducing the size and weight of machines.

# 4. High resolution


The 5-phase stepping motors have 0.72° per step in full-step mode and 0.36° per step in half-step mode-2.5 times the resolution of a 2-phase stepping motor. This makes it possible for extremely accurate positioning.

# 5. TH geared type


The backlash-proof geared stepping motor features the compact body: What's more, these motors allow high permissible torque. They are optimal for applications in which large torque is required in tight spaces.

## CSK SERIES SYSTEM CONFIGURATION

A compact stepping motor and driver are combined to provide high-precision positioning with open loop control.



## ACCESSORIES (Sold separately)



## **CSK** Series Standard Type

Page **B-179** 

Three sizes are available: **CSK54** with a frame size of 1.65 in. (42mm) sq.; **CSK56**□ 2.36 in. (60mm) sq.; and **CSK59**□ 3.35 in. (85mm) sq.

Package Model	Maximum Holding Torque oz-in N·m		
CSK543-NATA (Single Shaft)	18	0.13	
CSK543-NBTA (Double Shaft)	18	0.13	
CSK544-NATA (Single Shaft)	24.9	0.18	
CSK544-NBTA (Double Shaft)	24.9	0.18	
CSK545-NATA (Single Shaft)	33.3	0.24	
CSK545-NBTA (Double Shaft)	33.3	0.24	
CSK564-NATA (Single Shaft)	58.3	0.42	
CSK564-NBTA (Double Shaft)	58.3	0.42	
CSK566-NATA (Single Shaft)	115	0.83	
CSK566-NBTA (Double Shaft)	115	0.83	
CSK569-NATA (Single Shaft)	230	1.66	
CSK569-NBTA (Double Shaft)	230	1.66	
CSK596-NATA (Single Shaft)	291	2.1	
CSK596-NBTA (Double Shaft)	291	2.1	
CSK599-NATA (Single Shaft)	569	4.1	
CSK599-NBTA (Double Shaft)	569	4.1	
CSK5913-NATA (Single Shaft)	874	6.3	
CSK5913-NBTA (Double Shaft)	874	6.3	




#### **CSK** Series **TH** Geared Type Page **B-185**

Five gear ratio are available: 3.6:1, 7.2:1, 10:1, 20:1 and 30:1. The low ratio allows output shaft speed to be reduced without reducing the input pulse frequency, thus enabling more precise resolution and smoother rotation at low speed.

Package Model	Permissible Torque
	lb-in N⋅m
CSK543AA-TG3.6 (Single Shaft)	3.03 0.35
CSK543BA-TG3.6 (Double Shaft)	3.03 0.35
CSK543AA-TG7.2 (Single Shaft)	6.07 0.7
CSK543BA-TG7.2 (Double Shaft)	6.07 0.7
CSK543AA-TG10 (Single Shaft)	8.67 1
CSK543BA-TG10 (Double Shaft)	8.67 1
CSK543AA-TG20 (Single Shaft)	13 1.5
CSK543BA-TG20 (Double Shaft)	13 1.5
CSK543AA-TG30 (Single Shaft)	13 1.5
CSK543BA-TG30 (Double Shaft)	13 1.5
CSK564AA-TG3.6 (Single Shaft)	10.8 1.25
CSK564BA-TG3.6 (Double Shaft)	10.8 1.25
CSK564AA-TG7.2 (Single Shaft)	21.6 2.5
CSK564BA-TG7.2 (Double Shaft)	21.6 2.5
CSK564AA-TG10 (Single Shaft)	26 3
CSK564BA-TG10 (Double Shaft)	26 3
CSK564AA-TG20 (Single Shaft)	30.3 3.5
CSK564BA-TG20 (Double Shaft)	30.3 3.5
CSK564AA-TG30 (Single Shaft)	34.7 4
CSK564BA-TG30 (Double Shaft)	34.7 4




## **TH** Gear



The structure of the final stage of the TH gear

Tapered gears are used at the final stage of the spur gear train. As shown in the figure, two tapered gears contact and are designed to provide less backlash.

## PRODUCT NUMBER CODE



## ■ SPECIFICATIONS STANDARD TYPE

Doo	kaga Madal	Single Shaft	CSK543-NATA	CSK544-NATA	CSK545-NATA	CSK564-NATA	CSK566-NATA	CSK569-NATA		
Pac	kage Model -	Double Shaft	CSK543-NBTA	CSK544-NBTA	CSK545-NBTA	CSK564-NBTA	CSK566-NBTA	CSK569-NBTA		
Max	kimum Holding Torque	18	24.9	33.3	58.3	115	230			
IVIU		0.13	0.18	0.24	0.42	0.83	1.66			
Rote	or Inertia	oz-in <sup>2</sup>								
-	10	kg⋅ m²	35×10 <sup>-7</sup>	54×10 <sup>-7</sup>	68×10 <sup>-7</sup>	175×10 <sup>-7</sup>	280×10 <sup>-7</sup>	560×10 <sup>-7</sup>		
	ed Current	A/phase		0.75 1.4						
	ic Step Angle Jation Class		0.72°							
	ver Source		DC34	Class B [266°F (130°C)]  DC24V±10% 1.3A Maximum						
	put Current	A/phase	D024	0.75	annum	D024	1.4	annum		
Out	put ourrent	н/рпазе			(4 phase evaluation)	0.709/oton	1.4			
Exci	itation Mode				4 phase excitation) (4-5 phase excitation					
	Input Signal Circuit			out, Input resistance hotocoupler ON: +4						
	Pulse Signal			Step command pulse signal, Pulse width: 5µs minimum, Pulse rise/fall: 2µs maximum Motor moves when the photocoupler state changes from ON to OFF.						
nals	Rotation Direction Signal			Rotation direction signal Photocoupler ON: CW, Photocoupler OFF: CCW						
Input Signals	• Step Angle Signal			Full Step (0.72°) at "photocoupler ON" Half Step (0.36°) at "photocoupler OFF"						
	• All Windings Off Signal		When in the "photocoupler ON" state, the current to the motor is cut off and the motor shaft can be rotated manually. When in the "photocoupler OFF" state, the current level set by the RUN switch is supplied to the motor.							
	Automatic Current Cutback Release Signal		When in the "pho	When in the "photocoupler ON" state, the "Automatic Current Cutback" function at motor standstill is disabled. When in the "photocoupler OFF" state, the "Automatic Current Cutback" function at motor standstill is activated (approximately 100ms after motor stops).						
© Output Signal Circuit Photocoupler, Open-Collector Output Extern					ıt External use cond	ition: 24V DC maxii	mum, 10mA maxim	um		
Output Signals	• Excitation Timing Signal		The signal is output every time the excitation sequence returns to the initial stage "0".  (Photocoupler: ON) Full step: signal output every 10 pulses, Half step: signal output every 20 pulses							
Fun	ctions		Automatic current cutback							
Driv	er Cooling Method		Natural Ventilation							
Moi	aht (Mace)	Motor Ib. (kg)	0.47 (0.21)	0.6 (0.27)	0.78 (0.35)	1.33 (0.6)	1.77 (0.8)	2.87 (1.3)		
VVCI	Weight (Mass) Driver lb. (kg)		0.31 (0.14)							
Insu	ulation Resistance	$100 M\Omega$ minimum under normal temperature and humidity, when measured by a DC500V megger between the motor coils and the motor casing.								
Diel	ectric Strength	Motor	Sufficient to withstand 1.0kV (0.5kV for <b>CSK54</b> _type), 60Hz applied between the motor coils and casing for one minute, under normal temperature and humidity.							
۸ ۱	hiant Tananantuna Dany	Motor	+14°F~+122°F (-10°C~+50°C)							
	bient Temperature Range -			+32°F~+104	°F (0°C~+40°C)					

<sup>•</sup>Maximum holding torque refers to the holding torque at motor standstill when the rated current is supplied to the motor (5 phase excitation). Use this value to compare motor torque performance. When using the motor with the dedicated driver, the driver's "Automatic Current Cutback" function at motor standstill reduces maximum holding torque by approximately 50%.

<sup>•</sup>The power source input current value represents the maximum current. (The input current varies according to the pulse frequency.)

Note: Do not measure insulation resistance or perform the dielectric strength test while the motor and driver are connected.

## ■ SPECIFICATIONS STANDARD TYPE


Package Model		Single Shaft	CSK596-NATA	CSK599-NATA	CSK5913-NATA				
		Double Shaft	CSK596-NBTA	CSK599-NBTA	CSK5913-NBTA				
Maximum Holding To	orque	oz-in N · m	291 2.1	569 4.1	874 6.3				
Rotor Inertia		oz-in² kg· m²	7.66 1400×10 <sup>-7</sup>	14.8 2700×10 <sup>-7</sup>	21.9 4000×10 <sup>-7</sup>				
Rated Current		A/phase		2.8					
Basic Step Angle				0.72°					
Insulation Class			Class B [266°F (130°C)]						
Power Source				DC24V±10% 4A					
Output Current		A/phase		2.8					
Excitation Mode				4 phase excitation): 0.72°/step (4-5 phase excitation): 0.36°/step					
Input Signal Circ	cuit			220 $\Omega$ , Input current 20mA maximum $4\sim+5$ V, Photocoupler OFF: $0\sim+0.5$ V					
Pulse Signal (CW Pulse Sig	nal)		Pulse width: 5µs minimum, Pulse ris	Step command pulse signal (CW step command signal at 2-pulse input mode) Pulse width: 5µs minimum, Pulse rise/fall: 2µs maximum Motor moves when the photocoupler state changes from ON to OFF.					
Rotation Direct (CCW Pulse S)			Rotation direction signal Photocoup (CCW step command signal at 2-puls Pulse width: 5µs minimum, Pulse ri Motor moves when the photocouple	se/fall: 2µs maximum					
• Step Angle Sig	jnal		Full Step (0.72°) at "photocoupler ON Half Step (0.36°) at "photocoupler OF						
• All Windings (	Off Signal			the current to the motor is cut off and the, the current level set by the RUN switc					
Automatic Cur Release Signa		k		, the "Automatic Current Cutback" functi e, the "Automatic Current Cutback" funct tops).					
Output Signal Ci	rcuit		Photocoupler, Open-Collector Output	External use condition: 24V DC maxim	um, 10mA maximum				
• Excitation Tim	ing Signal		(Photocoupler: ON)	xcitation sequence returns to the initial sees, Half step: signal output every 20 pu					
• Overheat Sign	al		The signal is output when the internation 194°F (90°C). (Photocoupler: ON) The motor stops automatically if the	al temperature of the driver rises above automatic current off function is ON.	approximately				
Functions			Automatic current cutback, All windi	ngs off, Pulse input mode switch					
Driver Cooling Metho	d		Natural Ventilation						
Weight (Mass)		Motor Ib. (kg)	3.75 (1.7)	6.18 (2.8)	8.38 (3.8)				
vveigiit (iviass)		Driver Ib. (kg)		0.56 (0.25)					
Insulation Resistance	)		$100 M\Omega$ minimum under normal temperature and humidity, when measured by a DC500V megger between the motor coils and the motor casing.						
Dielectric Strength			Sufficient to withstand 1.0kV, 60Hz applied between the motor coils and casing for one minute, under normal temperature and humidity.						
Ambient Temperature	Range	Motor	+14°F~+122°F (-10°C~+50°C)						
7 minorial romporature	riango	Driver	+32°F~+104°F (0°C~+40°C)						

<sup>•</sup>Maximum holding torque refers to the holding torque at motor standstill when the rated current is supplied to the motor (5 phase excitation). Use this value to compare motor torque performance. When using the motor with the dedicated driver, the driver's "Automatic Current Cutback" function at motor standstill reduces maximum holding torque by approximately 50%.


The power source input current value represents the maximum current. (The input current varies according to the pulse frequency.)

fs: Maximum Starting Pulse Rate


#### CSK543-NBTA




### CSK564-NBTA




#### CSK544-NBTA




#### CSK566-NBTA



#### CSK545-NBTA




#### CSK569-NBTA




#### Note:

- •Pay attention to heat dissipation from the motor and driver. The motor will produce a considerable amount of heat under certain conditions. Be sure to keep the temperature of the motor case under 212°F (100°C).
- •When using the motor with the dedicated driver, the driver's "Automatic Current Cutback" function at motor standstill reduces maximum holding torque by approximately 50%.


### CSK596-NBTA



### CSK599-NBTA



### CSK5913-NBTA



- •Pay attention to heat dissipation from the motor and driver. The motor will produce a considerable amount of heat under certain conditions. Be sure to keep the temperature of the motor case under 212°F (100°C).
- •When using the motor with the dedicated driver, the driver's "Automatic Current Cutback" function at motor standstill reduces maximum holding torque by approximately 50%.

## DIMENSIONS

scale 1/4, unit = inch (mm)


### Motor

### CSK543-NATA (Single shaft)

Motor Model: PK543-NAA Weight 0.47lb. (Mass 0.21kg)

CSK543-NBTA (Double shaft)

Motor Model: PK543-NBA Weight 0.47lb. (Mass 0.21kg)




\*.59 $\pm$ .01 (15 $\pm$ 0.25) indicates the length of milling on motor shaft.

#### CSK544-NATA (Single shaft)

Motor Model: PK544-NAA Weight 0.6lb. (Mass 0.27kg)

CSK544-NBTA (Double shaft)

Motor Model: PK544-NBA Weight 0.6lb. (Mass 0.27kg)




\*.59 $\pm$ .01 (15 $\pm$ 0.25) indicates the length of milling on motor shaft.

### CSK545-NATA (Single shaft)

Motor Model: PK545-NAA Weight 0.78lb. (Mass 0.35kg)

CSK545-NBTA (Double shaft)

Motor Model: PK545-NBA Weight 0.78lb. (Mass 0.35kg)




- \*.59 $\pm$ .01 (15 $\pm$ 0.25) indicates the length of milling on motor shaft.
- These external appearance drawings are for double shaft models. For single shaft, ignore the colored areas.
- •See page B-36 for information on motor installation.

### CSK564-NATA (Single shaft)

Motor Model: PK564-NAA Weight 1.33lb. (Mass 0.6kg)

CSK564-NBTA (Double shaft)

Motor Model: PK564-NBA Weight 1.33lb. (Mass 0.6kg)




#### CSK566-NATA (Single shaft)

Motor Model: PK566-NAA Weight 1.77lb. (Mass 0.8kg)

CSK566-NBTA (Double shaft)

Motor Model: PK566-NBA Weight 1.77lb. (Mass 0.8kg)





## CSK569-NATA (Single shaft)

Motor Model: PK569-NAA Weight 2.87lb. (Mass 1.3kg)

CSK569-NBTA (Double shaft)

Motor Model: PK569-NBA Weight 2.87lb. (Mass 1.3kg)





- •These external appearance drawings are for double shaft models. For single shaft, ignore the colored areas.
- •See page B-36 for information on motor installation.

## PRODUCT NUMBER CODE

### Gear Ratio **TH** Geared Type CSK Series **USA** Version Shaft Type A: Single Shaft Motor Case Length B: Double Shaft Motor Frame Size 4: 1.65 in. (42mm) sq. 6: 2.36 in. (60mm) sq.

## ■ SPECIFICATIONS TH GEARED TYPE

Dan	kage Model	Single Shaft	ingle Shaft CSK543AA-TG3.6CSK543AA-TG7.2 CSK543AA-TG10 CSK543AA-TG20 CSK						
rac	raye Muuel	Double Shaft	CSK543BA-TG3.6	CSK543BA-TG7.2	CSK543BA-TG10	CSK543BA-TG20	CSK543BA-TG30		
Max	ximum Holding Torque	lb-in N · m	3.03 0.35	6.07 0.7	8.67 1	13 1.5	13 1.5		
Rot	or Inertia	oz-in² (kg· m²)	0.192 (35×10 <sup>-7</sup> )						
Rat	ed Current	A/phase	0.75						
Bas	ic Step Angle		0.2°	0.1°	0.072°	0.036°	0.024°		
Gea	r Ratio		3.6:1	7.2:1	10:1	20:1	30:1		
Per	missible Torque	lb-in N · m	3.03 0.35	6.07 0.7	8.67 1	13 1.5	13 1.5		
Per	missible Thrust Load	lb. (N)			3.3 (1.5)				
Per	missible Overhung Load	lb. (N)			4.4 (2.0)				
Bac	klash	Arcmin (deg)	45 (0.75°)	25 (0.417°)	25 (0.417°)	15 (0.25°)	15 (0.25°)		
Per	missible Speed Range	Full Step	0~15000Hz (0~500r/min)	0~15000Hz (0~250r/min)	0~15000Hz (0~180r/min)	0~15000Hz (0~90r/min)	0~15000Hz (0~60r/min)		
(Ge	ar Output Shaft Speed)	Half Step	0~30000Hz (0~500r/min)	0~30000Hz (0~250r/min)	0~30000Hz (0~180r/min)	0~30000Hz (0~90r/min)	0~30000Hz (0~60r/min)		
Insi	ulation Class			(	Class B [266°F (130°C)]				
Pov	ver Source			DC2	24V±10% 1.3A Maxim	num			
Out	put Current	A/phase			0.75				
F.v.o	itation Mada	Full Step	0.2°/step	0.1°/step	0.072°/step	0.036°/step	0.024°/step		
EXC	titation Mode Half Step 0.1°/step 0.05°/step 0.036°/step 0.018°/step						0.012°/step		
	Input Signal Circuit			nput resistance 220 $\Omega$ , locoupler ON: $+4\sim+5$ V,					
	• Pulse Signal		Step command pulse signal, Pulse width: 5µs minimum, Pulse rise/fall: 2µs maximum Motor moves when the photocoupler state changes from ON to OFF.						
Input Signals	Rotation Direction Signa	I	Rotation direction sig Photocoupler ON: CV	gnal V, Photocoupler OFF: C	CW				
ž	Step Angle Signal		Full Step (0.72°) whe	n "photocoupler ON"   F	Half Step (0.36°) when "	photocoupler OFF"			
≝┝	All Windings Off Signal		When in the "photocoupler ON" state, the current to the motor is cut off and the motor shaft can be rotated manual. When in the "photocoupler OFF" state, the current level set by the RUN switch is supplied to the motor.						
	Automatic Current Cutba Release Signal	ack		oupler ON" state, the "Au oupler OFF" state, the "A ns after motor stops).					
nais	Output Signal Circuit		Photocoupler, Open-	Collector Output Exterr	nal use condition: 24V D	OC maximum, 10mA ma	ıximum		
Uutput Signais	• Excitation Timing Signal			every time the excitation ut every 10 pulses, Half			ocoupler: ON)		
	ctions		Automatic current cu			, . ,			
	ver Cooling Method		Natural Ventilation						
		Motor Ib. (kg)							
Wei	ight (Mass)	Driver Ib. (kg)	0.31 (0.14)						
Insi	ulation Resistance	Motor	$100M\Omega$ minimum under normal temperature and humidity, when measured by a DC500V megger between the motor coils and the motor casing.						
Die	lectric Strength	Motor	Sufficient to withstand 1.0kV (0.5kV for <b>CSK54</b> type), 60Hz applied between the motor coils and casing for one minute, under normal temperature and humidity.						
۸	hiant Tamparatura Dana	Motor	+14°F~+122°F (-10°C~+50°C)						
Ambient Temperature Range Driver		+32°F~+104°F (0°C~+40°C)							

<sup>•</sup>Maximum holding torque refers to the holding torque at motor standstill when the rated current is supplied to the motor (5 phase excitation). Use this value to compare motor torque performance. When using the motor with the included driver, the driver's "Automatic Current Cutback" function at motor standstill reduces maximum holding torque by approximately 50%.

<sup>•</sup>The power source input current value represents the maximum current. (The input current varies according to the pulse frequency.)

Permissible torque is the maximum value of the mechanical strength of the gear unit. Use the product with a total torque (load and acceleration) less than the permissible

Permissible overhung load indicates the maximum value measured at 0.39 in. (10mm) from the tip of the gear output shaft.

<sup>•</sup> The direction of rotation for the motor and that of the gear output shaft are the same for the gear ratios of 3.6:1, 7.2:1 or 10:1. They are opposite for 20:1 or 30:1 ratio types.

## ■ SPECIFICATIONS TH GEARED TYPE

Doo	kaga Madal		CSK564AA-TG3.6					
Package Model		Double Shaft	CSK564BA-TG3.6	CSK564BA-TG7.2	CSK564BA-TG10	CSK564BA-TG20	CSK564BA-TG30	
Max	kimum Holding Torque	lb-in N · m	10.8 1.25	21.6 2.5	26 3	30.3 3.5	34.7 4	
Rot	or Inertia	oz-in² (kg· m²)			0.96 (175×10 <sup>-7</sup> )		1	
Rate	ed Current	A/phase			1.4			
Bas	ic Step Angle		0.2°	0.1°	0.072°	0.036°	0.024°	
Gea	r Ratio		3.6:1	7.2:1	10:1	20:1	30:1	
Per	missible Torque	lb-in N · m	10.8 1.25	21.6 2.5	26 3	30.3 3.5	34.7 4	
Per	missible Thrust Load	lb. (N)			8.81 (40)			
Per	missible Overhung Load	lb. (N)			22 (100)			
Bac	klash	Arcmin (deg)	35 (0.584°)	15 (0.25°)	15 (0.25°)	10 (0.167°)	10 (0.167°)	
Peri	missible Speed Range	Full Step	0~15000Hz (0~500r/min)	0~15000Hz (0~250r/min)	0~15000Hz (0~180r/min)	0∼15000Hz (0∼90r/min)	0~15000Hz (0~60r/min)	
	ar Output Shaft Speed)	Half Step	0~30000Hz (0~500r/min)	0~30000Hz (0~250r/min)	0~30000Hz (0~180r/min)	0~30000Hz (0~90r/min)	0~30000Hz (0~60r/min)	
Insu	ulation Class		,	(	Class B [266°F (130°C)]		, ,	
	ver Source			DC2	24V±10% 2.1A Maxim	ium		
Out	put Current	A/phase			1.4			
F	Station Bands	Full Step	0.2°/step	0.1°/step	0.072°/step	0.036°/step	0.024°/step	
Excitation Mode	itation iviode	Half Step	0.1°/step	0.05°/step	0.036°/step	0.018°/step	0.012°/step	
	Input Signal Circuit				Input current 20mA max Photocoupler OFF: 0~			
	Pulse Signal		Step command pulse signal, Pulse width: 5µs minimum, Pulse rise/fall: 2µs maximum Motor moves when the photocoupler state changes from ON to OFF.					
Input Signals	Rotation Direction Signa	I	Rotation direction sig	nal V. Photocoupler OFF: C	CW			
ont S	Step Angle Signal		Full Step (0.72°) when "photocoupler ON" Half Step (0.36°) when "photocoupler OFF"					
≝⊦	• All Windings Off Signal		When in the "photocoupler ON" state, the current to the motor is cut off and the motor shaft can be rotated When in the "photocoupler OFF" state, the current level set by the RUN switch is supplied to the motor.					
	Automatic Current Cutba Release Signal	ck		oupler OFF" state, the "A	ntomatic Current Cutbac utomatic Current Cutbac			
nals	Output Signal Circuit		Photocoupler, Open-	Collector Output Extern	nal use condition: 24V D	C maximum, 10mA ma	aximum	
Output Signals	• Excitation Timing Signal				sequence returns to th step: signal output eve		ocoupler: ON)	
	ctions		Automatic current cutback					
	ver Cooling Method		Natural Ventilation					
		Motor Ib. (kg)	2.1.(2.2)					
wei	ght (Mass)	Driver Ib. (kg)						
Insulation Resistance Motor			$100M\Omega$ minimum under normal temperature and humidity, when measured by a DC500V megger between the motor coils and the motor casing.					
Diel	ectric Strength	Motor	Sufficient to withstand 1.0kV, 60Hz applied between the motor coils and casing for one minute, under normal temperature and humidity.					
Λ '	hiant Tamparatura Dana	Motor	+14°F~+122°F (-10°C~+50°C)					
AM	Ambient Temperature Range Driver		+32°F~+104°F (0°C~+40°C)					

<sup>•</sup>Maximum holding torque refers to the holding torque at motor standstill when the rated current is supplied to the motor (5 phase excitation). Use this value to compare motor torque performance. When using the motor with the included driver, the driver's "Automatic Current Cutback" function at motor standstill reduces maximum holding torque by approximately 50%.

The power source input current value represents the maximum current. (The input current varies according to the pulse frequency.)


<sup>•</sup>Permissible torque is the maximum value of the mechanical strength of the gear unit. Use the product with a total torque (load and acceleration) less than the permissible torque.

<sup>•</sup>Permissible overhung load indicates the maximum value measured at 0.39 in. (10mm) from the tip of the gear output shaft.


<sup>•</sup> The direction of rotation for the motor and that of the gear output shaft are the same for the gear ratios of 3.6:1, 7.2:1 or 10:1. They are opposite for 20:1 or 30:1 ratio types.

### fs: Maximum Starting Pulse Rate


#### CSK543BA-TG3.6




### CSK543BA-TG7.2




### CSK543BA-TG10




## CSK543BA-TG20




#### CSK543BA-TG30




#### CSK564BA-TG3.6



#### CSK564BA-TG7.2



#### CSK564BA-TG10




#### Note


- •Pay attention to heat dissipation from the motor and driver. The motor will produce a considerable amount of heat under certain conditions. Be sure to keep the temperature of the motor case under 212°F (100°C).
- •When using the motor with the dedicated driver, the driver's "Automatic Current Cutback" function at motor standstill reduces maximum holding torque by approximately 50%.

fs: Maximum Starting Pulse Rate

#### CSK564BA-TG20



#### CSK564BA-TG30



- •Pay attention to heat dissipation from the motor and driver. The motor will produce a considerable amount of heat under certain conditions Be sure to keep the temperature of the motor case under 212°F (100°C).
- •When using the motor with the dedicated driver, the driver's "Automatic Current Cutback" function at motor standstill reduces maximum holding torque by approximately 50%.

## PRECAUTIONS

When using the **CSK TH** geared type, please note the following:

## Do not exceed the maximum permissible torque:

Permissible torque represents the maximum value of the mechanical strength of the gear unit. Be sure to keep the total value of acceleration/deceleration torque and load (friction) torque at the shaft under the permissible torque value. If torque exceeding the permissible torque is applied, the gear unit may

## Do not exceed the permissible speed range:

Do not exceed the maximum output speed of the gearhead indicated in the specifications on page B-185 and B-186. The speed affects the life of the gearhead.

## Consider backlash in bi-directional positioning:

Backlash is the free rotation angle (i.e., play) of the output shaft when the input section of the reduction gear is fixed. The CSK **TH** geared type is a highly accurate gear for positioning. CSK564TG models provides 35 arc minutes (for gear ratio 3.6:1),15 arc minutes (for gear ratios 7.2:1 and 10:1) and 10 arc minutes (for gear ratios 20:1 and 30:1). If there is a problem with backlash in positioning in both directions, be sure to stop the motor in one direction. (In CSK543TG models, backlash is 45 arc minutes, 25 arc minutes and 15 arc minutes, respectively, for the above gear ratios.)

## 4. The direction of gear-shaft rotations differs according to gear ratios:

The direction of motor shaft rotation and gear shaft rotation according to the gear ratio applied:

Gear ratio - 3.6:1, 7.2:1 or 10:1 - Same as motor shaft Gear ratio - 20:1 or 30:1 - Opposite of motor shaft


## DIMENSIONS

### scale 1/4, unit = inch (mm)

### Gearmotor

CSK543AA-TG3.6 (Single shaft) Motor Model: PK543ANA-TG3.6 CSK543AA-TG7.2 (Single shaft) Motor Model: PK543ANA-TG7.2 CSK543AA-TG10 (Single shaft) Motor Model: PK543ANA-TG10 CSK543AA-TG20 (Single shaft) Motor Model: PK543ANA-TG20 CSK543AA-TG30 (Single shaft) Motor Model: PK543ANA-TG30 CSK543BA-TG3.6 (Double shaft) Motor Model: PK543BNA-TG3.6 CSK543BA-TG7.2 (Double shaft) Motor Model: PK543BNA-TG7.2 CSK543BA-TG10 (Double shaft) Motor Model: PK543BNA-TG10 CSK543BA-TG20 (Double shaft) Motor Model: PK543BNA-TG20 CSK543BA-TG30 (Double shaft) Motor Model: PK543BNA-TG30

Weight 0.73lb. (Mass 0.33kg)




Screws (included) 4-No.8-32 UNC. length .39 (10)

#### \*.59 $\pm$ .01 (15 $\pm$ 0.25) indicates the length of milling on motor shaft.

CSK564AA-TG3.6 (Single shaft) Motor Model: PK564ANA-TG3.6 CSK564AA-TG7.2 (Single shaft) Motor Model: PK564ANA-TG7.2 CSK564AA-TG10 (Single shaft) Motor Model: PK564ANA-TG10 CSK564AA-TG20 (Single shaft) Motor Model: PK564ANA-TG20 CSK564AA-TG30 (Single shaft) Motor Model: PK564ANA-TG30 CSK564BA-TG3.6 (Double shaft) Motor Model: PK564BNA-TG3.6 CSK564BA-TG7.2 (Double shaft) Motor Model: PK564BNA-TG7.2 CSK564BA-TG10 (Double shaft) Motor Model: PK564BNA-TG10 CSK564BA-TG20 (Double shaft) Motor Model: PK564BNA-TG20 CSK564BA-TG30 (Double shaft) Motor Model: PK564BNA-TG30

Weight 2.09lb. (0.95kg)




• These external appearance drawings are of double shaft model. For a single shaft, ignore the colored areas.

See page B-36 for information on motor installation, and page B-38 for information on driver installation.

### Driver

Driver: CSD5807N-T (For CSK543TG models) CSD5814N-T (For CSK564TG models) Weight: 0.31lb. (Mass 0.14kg)




## ■ LIST OF MOTOR AND DRIVER COMBINATIONS

		Stepping motor	Driver	
Туре	Package model	Model	Current A/phase	Model
	CSK543-N□TA CSK544-N□TA CSK545-N□TA	PK543-N□A PK544-N□A PK545-N□A	0.75	CSD5807N-T
STANDARD	CSK564-N□TA CSK566-N□TA CSK569-N□TA	PK564-N□A PK566-N□A PK569-N□A	1.4	CSD5814N-T
	CSK596-N□TA CSK599-N□TA CSK5913-N□TA	PK596-N□A PK599-N□A PK5913-N□A	2.8	CSD5828N-T
TH GEARED	CSK543□A-TG3.6 CSK543□A-TG7.2 CSK543□A-TG10 CSK543□A-TG20 CSK543□A-TG30	PK543_NA-TG3.6 PK543_NA-TG7.2 PK543_NA-TG10 PK543_NA-TG20 PK543_NA-TG30	0.75	CSD5807N-T
IN GEARED	CSK564□A-TG3.6 CSK564□A-TG7.2 CSK564□A-TG10 CSK564□A-TG20 CSK564□A-TG30	PK564\(\text{NA-TG3.6}\) PK564\(\text{NA-TG7.2}\) PK564\(\text{NA-TG10}\) PK564\(\text{NA-TG20}\) PK564\(\text{NA-TG30}\)	1.4	CSD5814N-T

Enter  $\bf A$  (single shaft) or  $\bf B$  (double shaft) in the  $\Box$  within the model numbers.

## WIRING DIAGRAMS

- **●CSK54**□, **CSK56**□ Models
- CSK543TG. CSK564TG Models




#### Note:

•Keep the voltage Vo1 and Vo2 between DC 5V and DC 24V.

When they are equal to DC 5V, the external resistances R1 and R2 are not neccessory. When they are above DC 5V, connect R1 to keep the current below 20mA, and connect R2 to keep the current below 10mA.

- •Use twisted-pair wire of  $3.1 \times 10^{-4}$  in.<sup>2</sup> (0.2mm<sup>2</sup>) or thicker and 6.6 feet (2m) or less in length for the signal line.
- •Use wire  $7.8 \times 10^{-4}$  in.<sup>2</sup> (0.5mm<sup>2</sup>) or thicker for motor lines (when extended) and power supply lines, and use  $1.2 \times 10^{-3}$  in.<sup>2</sup> (0.75mm<sup>2</sup>) or thicker for the grounding wire.
- •Use spot grounding to ground of the driver and external controller.
- Signal lines should be kept at least 3.94 in. (10cm) away from power lines (power supply lines and motor lines). Do not bind the signal line and power line together.

## Timing Chart



## Input/Output Signal

## Pulse Input

"Pulse" signal is input to the PULSE – terminal. The direction of rotation is determined by the following rotation direction signal.

## Rotation Direction Input

The "Rotation Direction" signal is input to the DIRECTION – terminal.

"Photocoupler ON" : CW
"Photocoupler OFF" : CCW

## All Windings Off (AW. OFF) Input

When the "All Windings Off" (AW. OFF) signal is in the "photocoupler ON" state, the current to the motor is cut off and motor holding torque is reduced to zero. The motor output shaft can then be rotated freely by hand.

This signal is used when moving the motor by external force or the manual home position.

## Step Angle (FULL/HALF) Input

When the "Step Angle" (FULL/HALF) signal is in the "photocoupler ON" state, half step mode (0.36°/step) has been selected; when the FULL/HALF signal is in the "photocoupler OFF" state, full step mode (0.72°/step) has been selected.

### Automatic Current Cutback Release

## (C.D.INH) Input


When the "Automatic Current Cutback" release (C.D.INH) signal is in the "photocoupler ON" state, the "Automatic Current Cutback" function is not activated.

## Excitation Timing (TIMING) Output


The signal is output once each time the excitation sequence returns to step "0" in synchronization with input pulses. The excitation sequence is designed to complete one cycle as the motor shaft rotates 7.2°. A signal is output every 10 pulses in full step mode (0.72°/step) and every 20 pulses in half step mode (0.36°/step).


- Note: 10µs or more is the standard interval time for switching from CW to CCW. Note that the interval time greatly varies according the motor and load inertia.
- \*1 It is recommended to wait a period of time to allow the motor oscillations to end before inputting the A.W.O signal. This time varies with the load inertia, the load torque and the starting pulse rate. The signal input must be stopped before the motor stops.
- Never input a step pulse signal immediately after switching the "All Windings Off" signal to "H" level or the motor may lose synchronism. In general, an interval of 100m sec. (minimum) is required.

## CSK59 ☐ Model



## **■ Timing Chart**





## Input/Output Signal

### Pulse Input

## 1-Pulse Input Mode

#### Pulse Signal

"Pulse" signal is input to the P./CW — terminal. When the photocoupler state changes from "ON" to "OFF", the motor rotates one step. The direction of rotation is determined by the following rotation direction signal.

### **Rotation Direction Signal**

The "Rotation Direction" signal is input to D./CCW – terminal.

A "photocoupler ON" signal input commands a clockwise direction rotation. A "photocoupler OFF" signal input commands a counter-clockwise direction rotation.

### 2-Pulse Input Mode

### CW Pulse Signal

"Pulse" signal is input to the P./CW – terminal. When the photocoupler state changes from "ON" to "OFF", the motor rotates one step in the clockwise direction.

#### **CCW Pulse Signal**

"Pulse" signal is input to the D./CCW – terminal. When the photocoupler state changes from "ON" to "OFF", the motor rotates one step in the counterclockwise direction

## Overheat (O.HEAT) Output

The overheat signal is output to protect the driver from heat damage if the internal temperature of the driver rises above 194°F (90°C).

At the same time this signal is output, the O.H.LED on the circuit board lights. The O.HEAT signal is automatically turned off when the temperature of the driver heat sink falls. (The O.HEAT signal returns to the "photocoupler OFF" state, and O.H.LED goes off.)

Note: Except for the above, signals are the same as those for the CSK54□ and CSK56□. (See Page B-191.)

#### Note:

- •Keep the voltage Vo1 and Vo2 between DC 5V and DC 24V.
  When they are equal to DC 5V, the external resistances R1 and R2 are not neccessory. When they are above DC 5V, connect R1 to keep the current below 20mA, and connect R2 to keep the current below 10mA.
- $\bullet$  Use twisted-pair wire of 3.1  $\times$  10  $^4\text{in}^2(0.2\text{mm}^2)$  or thicker and 6.6 feet (2m) or less in length for the signal line.
- •The suitable wire size for the CN1 and CN2 connectors is between AWG20 and 26. Use wires rated at AWG20 (0.5mm²) for the power line.
- •Signal lines should be kept at least 3.94 in. (10cm) away from power lines (power supply lines and motor lines). Do not bind the signal line and power line together.
- If noise generated by the motor lead wire causes problem, try shielding of the motor lead wires with conductive tape or wire mesh.
- \*1 When the signal is in the "photocoupler ON" state, the "Automatic Current Cutback" function is deactivated. Always set it in the "photocoupler OFF" state when the pulse signal is stopped.
- \*2 It is recommended to wait a period of time to allow the motor oscillations to end before inputting the "All Windings Off" signal. This time varies with the load inertia, the load torque and the starting pulse rate. Signal input must be stopped before the motor stops.
- \*3 Do not input pulse signals immediately after switching the "All Windings Off" input signal into the "photocoupler OFF" state, as this will affect the motor's start-up characteristics. Ordinarily, the interval should be around 100ms
- \*4 The motor will not operate properly when inputting a pulse signal while either the CW or CCW pulse is in the "photocoupler ON" state.

## ADJUSTING THE OUTPUT CURRENT

### 1. Adjustment Method


The rated output current is set at the factory. When it is necessary to change the current setting, follow the procedures described below.

#### Connecting an ammeter

•CSK54□, CSK56□ Models


•CSK543□A-TG□, CSK564□A-TG□ Models

Connect a DC ammeter between the motor and terminal ① of TB1 connector as shown below.



### •CSK59 ☐ Model

Connect a DC ammeter between the motor and terminal ① of the MOTOR connector as shown below.



- After connecting the DC ammeter to the motor, turn on the power.
   (The excitation status at this point is fixed: power on reset.)
- When the power is turned on, the motor enters a 4 phase excitation state, and +directional positive current flows through the blue motor lead wire. (Even if 4-5 phase excitation has been selected, the motor enters a 4 phase excitation state when the power is turned on. Adjust the current in this state.)
- The value measured by the ammeter represents the total current in two phases. The current for one phase is equivalent to half of the ammeter value. (When setting the current to 1.0A/phase, adjust the current level until the ammeter reads 2.0A.)

## 2. Adjusting the Motor Operating Current

Set the "Automatic Current Cutback" release (C.D.INH) signal to the "photocoupler ON" state (SW: ON) when adjusting the RUN current.

(1) Adjust the motor RUN current with the RUN potentiometer.
Adjusting Range CSD5807N-T: 0.1A/phase~0.75A/phase

CSD5814N-T: 0.1A/phase~1.4A/phase CSD5828N-T: 1.0A/phase~2.8A/phase

(2)The motor operating current is set for rated current (CSD5807N-T: 0.75A/phase, CSD5814N-T: 1.4A/phase, CSD5828N-T: 2.8A/phase) at the time of shipping, but it can be readjusted using the RUN potentiometer. The operating current can be lowered to suppress temperature rise in the motor/driver, or lower operating current in order to allow a margin for motor torque or to reduce vibration.

Note: The motor RUN current should be less than the motor rated current.

## 3. Adjusting the Current at Motor Standstill

Set the "Automatic Current Cutback" release (C.D.INH) signal to the "photocoupler OFF" state (SW: OFF) when adjusting the current while the motor is stopped.

 Adjust the current at motor standstill with the STOP potentiometer.

Adjusting Range CSD5807N-T: 0.1A/phase~0.56A/phase

CSD5814N-T: 0.1A/phase~1.05A/phase CSD5828N-T: 0.7A/phase~2.3A/phase

(2)At the time of shipping, the current at motor standstill is set for half the rated current. (CSD5807N-T: 0.375A/phase, CSD5814N-T: 0.7A/phase, CSD5828N-T: 1.4A/phase). The STOP potentiometer can be used to readjust the current at motor standstill to the current value required to produce enough holding torque.

$$\begin{tabular}{lll} \mbox{Rated Holding} & \mbox{Current at Motor} \\ \mbox{Holding Torque} & = & & \mbox{Standstill } [A] \\ \mbox{Motor Rated Current } [A] \\ \end{tabular}$$